


Tips for use

Quooker CUBE



Operation Flex/Fusion/Nordic tap



Filtered chilled water: push-wait-turn
LED ring: solid blue



Filtered chilled sparkling water: push-turn
LED ring: flashing blue

Operation Front tap



Filtered chilled water: turn to the first click
LED ring: solid blue



Filtered chilled sparkling water:
turn to the second click
LED ring: flashing blue

First use

Before first use flush both the chilled and the sparkling water through twice for one minute each time (the tap switches off automatically after one minute). The water in the CUBE takes approximately 40 minutes to cool down after installation, depending on the incoming mains water temperature.

Settings

You can adjust the settings on the display. Navigate through the menu with the left and right arrow keys and confirm your selection with the middle button. You can:

- Change the language
- Set the effervescence level of the water
- View the status of the CO₂ cylinder

Daily use

After you have dispensed sparkling water, there will be a short overrun of chilled water, in order to rinse any sparkling residue from the tap.

Replacing the CO₂-cylinder

After approximately 60 litres of sparkling water has been dispensed, the water flow will become weaker and there will be less carbon dioxide in the water. The CO₂ cylinder then needs to be replaced. When the CO₂ cylinder is completely empty, no more water comes out of the tap when you try to dispense sparkling water.

You can order a set of four new CO₂ cylinders using your account at [quooker.com](https://www.quooker.com). Instructions are printed on the cylinders, explaining how you can easily replace them yourself. After you have replaced the cylinder, you can reset the CO₂ counter using the touchscreen display on the CUBE.

Returning the CO₂ cylinders

The used CO₂ cylinders can be returned to Quooker free of charge. The cylinders are loan cylinders and remain the property of Quooker. If the used cylinders are not returned within 14 days of receipt of the new cylinders, Quooker is entitled to invoice the user for the costs of the cylinders that have not been returned. For quality and safety reasons, the cylinders are refilled by Quooker. Visit quooker.com for more information about the return process.

Replacing the filter

The CUBE is equipped with an Active Carbon and Hollow Fibre filter. The Active Carbon filter guarantees better water quality because it reduces unpleasant tastes and odours. The Hollow Fibre filter purifies the incoming water of any bacteria that it may still contain. It also removes sand particles and suspended dust from the water. The filter lasts for 12 months or 3,500 litres. The CUBE will beep when the filter needs to be replaced. This signal can be snoozed for 72 hours using the snooze button on the display. During this time, you can order a new filter set from quooker.com.

Holiday

If you go on holiday for longer than two weeks, it is cheaper to switch off your CUBE. You can use the display to do this. When you return home, it is important to flush both the chilled and the sparkling water in the same way as specified under the section 'First use'.

Maintenance

Quooker recommends that you clean the CUBE fan once a year with a brush or vacuum cleaner. In addition, the filter must be replaced every 12 months.

Register your Quooker CUBE

Quooker products come with a two-year warranty. Scan the QR code below or go to quooker.com/register to register your CUBE. This enables us to help you faster if you have any questions.

Do you have any questions?

If you have questions or if you have an issue with your CUBE, go to quooker.com or use our self service tool at quooker.com/self-service. If the answer to your question is not on our website, log in to your My Quooker account or easily create a My Quooker account to contact our service department.



Serial number Quooker CUBE

Write down the serial number of your CUBE here. The number is displayed on the front of the CUBE.

